



30G Outdoor Cabinet



45G Outdoor Cabinet



60G Outdoor Cabinet



90G Outdoor Cabinet



NEW Outdoor Flammable Safety Cabinet



New Features

- Slanted top with rain gutter to guide rain or snow away from the cabinet opening
- Fully spot welded Galvanneal 18 gauge steel double wall construction with 1 1/2" gap for air space, 16 times more corrosive resistance than regular steel creating a rust-resistant cabinet when outdoors
- Stainless steel hinges
- Stainless steel paddle handle lock with three-point latching securing the contents
- Stable trapezoid legs
- OSHA, NFPA, IFC compliant and FM approved

Also Includes these standard features:

- Spill Slope shelves with fully welded sump
- Ground Screw
- Durable & Chemical –resistant powder coated paint
- UV Resistant
- Vent with built in flash arrestors
- Welded Shelf Hangers
- Leak Proof Sump

Safeguard your hazardous materials in Justrite's weather-resistant outdoor flammable safety cabinet

Justrite's Outdoor Safety Cabinet Details



Spill Control & Leak Collection
Patented SpillSlope® safety shelves direct spills to the back and bottom of the leakproof sump. 2in (51mm) leakproof containment sump holds leaks.

Stable Shelves
Welded shelf hangers interlock with the shelf to offer maximum stability, adjustable on 3in. (76mm) centers.

Lockable-U-Loc™
Stainless Steel Paddle latch handle includes a double key set or can be padlocked (not included).

Reliable Hinges
Continuous stainless steel piano hinges ensure your cabinet doors close smoothly and reliably for the life of your cabinet.

Automatic Closing Doors
Fusible links hold doors wide open and melt at 165°F (74°C) for automatic closure (on self-closing models) to prevent fire outside the cabinet.

Stable Trapezoid Legs
New 12 Gauge leg for durability and open design allowing tools to adjust, mount, or add accessories.

Outdoor Flammable Safety Cabinet Vs The Competition

Features:	Justrite®	Competition
Durable & Chemical Resistant Powder Coat Paint	●	●
Slanted TOP with Rain Gutter	●	●
Stainless Steel Hinges	✓	
Stainless Steel PaddleHandle 3-Point Latch	✓	
Fork Liftable Legs	✓	
Fully Spot Welded Galvanneal Steel	●	●
Vent with Built in Flash Arrestors	●	●
Welded Shelf Hangers	✓	
Leak Proof Sump	●	●
Extra Hem on Door for Seal Protection	✓	

Outdoor Flammable Safety Cabinet SET UP INFO

Model	Model Number	UPC
30G Manual Close NEW Outdoor Cabinet	813000	697841272330
30G Self Close NEW Outdoor Cabinet	813020	697841272347
45G Manual Close NEW Outdoor Cabinet	814500	697841272309
45G Self Close NEW Outdoor Cabinet	814520	697841272316
60G Manual Close NEW Outdoor Cabinet	816000	697841272385
60G Self Close NEW Outdoor Cabinet	816020	697841272392
90G Manual Close NEW Outdoor Cabinet	819000	697841272408
90G Self Close NEW Outdoor Cabinet	819020	697841272415



Warranty

- 10-year Structural
- 1-year Serviceable Parts

Proudly Offered By:

